



Windscreen Mirror Kit Installation Instructions For MG TC-TF

PART # 165-511, 165-512, 165-513, 165-514

440 Rutherford St. Goleta, CA 93117

1-800-667-7872 • FAX 805-692-2525 • www.mossmotors.com

Tools required:

Flat screw driver
(2x) 1/2" Combination wrenches

- 1) Assemble the mirror base to the mirror using the supplied screws. The slot in the mirror base hold down should be pointing to the bottom of the mirror. Gently snug the screws evenly but do not fully tighten them.



- 2) Remove the nut, lock washer, flat washer and rubber foot from the mirror base. The washers and rubber foot will not be reused.



- 3) Assemble the mirror base to the windscreen mirror bracket using the nut removed in the previous step. The contour of the mirror base should follow the contour of the bracket. Tighten the nut to secure the bracket to the base using a 1/2" wrench. Install the dome nut and use another 1/2" wrench to tighten it down.



- 4) Remove the wing nut from the windscreen. Install the mirror assembly over the stud and reinstall the wing nut and tighten it down. The largest hole in the mirror bracket should surround the windscreen-pivot hardware.



Installation Instructions



Illustration 4 cont.



- 5) Sit in the driver's seat and adjust the mirror to your liking. Once adjusted, tighten the three screws down evenly to hold the mirror stationary. Enjoy your new windscreen mirror and see www.mossmotors.com for all your T-series needs!