



440 Rutherford St. P.O. Box 847 Goleta, CA 93117
1-800-667-7872 • FAX 805-692-2525 • www.mossmotors.com

Installation Instructions Windblocker

For MGB
Part# 458-328

Tools required: a large Phillips screwdriver

1) Put the convertible top frame up on the vehicle without securing the fabric to the body or the frame to the windshield. Flip the back window and fabric over on the top so that you have access to the convertible top frame brackets and screws. Tilt both seats forward. Illustration 1.



Illustration 1

2) Remove the three screws from the left side of the convertible top bracket. Gather the left and right side wind blocker brackets. Refer to illustration 2 for left and right. Slip the wind blocker brackets in between the convertible top brackets and the interior side panel. Align the round hole in the wind stop bracket with the rear most hole in the convertible top bracket. Align the slotted hole in the wind blocker bracket with the bottom most hole in the convertible top bracket. Reinstall the stock hardware through the convertible top and wind blocker brackets finger tight. Repeat this process for the right side. Illustration 2.



Illustration 2



Windblocker Installation Instructions



Illustration 2 cont.



Illustration 3 cont.

3) Gather the wing bolts, all the washers and the wind blocker. Install one of the metal flat washers and one of the fiber washers onto each wing bolt. Position the wind blocker in the car so that the L-brackets on the bottom corners of the wind blocker point forward. This will give the seats the most room. Slip a fiber washer between the L-brackets on the blocker and the wind blocker brackets installed in the previous step. Install the wing bolts with the washers on, through the L-brackets and into the wind blocker brackets. Adjust the brackets as necessary and tighten the three screws on each convertible top bracket. Now adjust the wind blocker as you see fit and tighten the wing bolts to hold it in position. Illustration 3.



Illustration 3