

## TR6 Suffolk Seats (Pair)

**Part Number:** 646-560  
**Description:** Suffolk Seats  
**Applications:** TR6



## Fitting To Car

The seat slides supplied have a stud welded to the upper rail.

- 1 Insert studs onto base of seat and fix in place with nyloc nuts supplied.
- 2 Place the complete seat in the car and mark position of front holes on the floor pan.
- 3 If you can reach rear holes - mark their position also (access is limited due to the height of seat at its rear).

**OR**

- 4 Lift seat out of car onto work bench.
- 5 Measure rear hole centres and measure and mark on floor pan - using front hole positions as a reference.
  - ie a) Measure distance from each front hole.
  - b) Diagonals.
  - c) Width across rear holes.

This will give you the four hole positions.

- 6 Drill holes in the floor.
- 7 Remove slides from your seat and bolt to floor (studs facing up).
- 8 Place seat onto studs - fix in place with nyloc nuts.

