


## Supplemental Information & Instructions for 540-280 (GEU250) Alternator Plug Kit

Many MGB's and TR6s with internally regulated alternators are wired for two plugs with a total of five electrical terminals. The five-terminal alternator design has been obsolete for years, and the alternators available for these applications have a single plug with three terminals. The following wiring instructions, based on information provided by Lucas, explain how to make the conversion.



### Instructions

1. Disconnect battery.
2. Cut/peel back enough of the wiring harness tape to expose the end of the link wire loop (E).
3. Remove and discard the link wire (E).
4. Cut the alternator wires (A,B,C,D) as close to the original 5-Terminal Connectors as possible.
5. The black wire (B) is no longer used. Cover end with electrical tape, fold wire back into the harness and wrap w/tape.
6. The (A) wire (Brown in MGB, Brown-Green in TR6) is also no longer used. Cover end with electrical tape, fold wire back into the harness and wrap w/tape.
7. The black plastic plug has two parts, the insulator (R) and the cap (S). The insulator has three slots, one small (M) and two large (N).
8. Find the Brown-Yellow Indicator lead wire (D). Strip the end of the wire and solder it to the small flag terminal (O).
9. Feed the wire and terminal into the plug so the open end of the terminal is visible in the small slot (M).
10. Find the Brown (MGB) or Brown-White (TR6) Positive lead wire (C). Strip the end of the wire and solder it to one of the two large flag terminals (P).
11. Feed the wire and terminal into the plug so the open end of the terminal is visible in either of the large slots (N). *The Positive Lead can connect to either of the two large spade terminals (K) on the alternator, so it does not matter which large slot in the plug you choose.*
12. Snap the cap (S) on top of the insulator (R).
13. Plug the black plastic connector (T) into the three terminal socket on the alternator. The small brown/yellow IND lead (F) should connect to the small terminal (J) on the alternator. The Positive Lead (G) should connect to either of the two large terminals (K) on the alternator.
14. Re-Connect the battery.

Any suggestions that you may have that will improve the information (especially detailed installation notes) are welcome. Please use the simple email form on the "Contact Us" page on the Moss website: <http://www.mossmotors.com/AboutMoss/ContactUs.aspx>  
If you prefer, you may call our Technical Services Department at 805-681-3411.



### Moss Motors, Ltd.

440 Rutherford Street, Goleta, California 93117  
In the US & Canada Toll Free (800) 667-7872 FAX (805) 692-2510 (805) 681-3400

### Moss Europe Ltd.

Hampton Farm Industrial Estate, Hampton Road West, Hanworth Middlesex, TW13 6DB  
In the UK: 020-8867-2020 FAX:- 020-8867-2030